# **Powering Your Ring**

Charge your Ring Doorbell before installation using the supplied orange cable.

While charging, the circular light on the front of your Ring will let you know the percentage it's charged.

If you have an existing doorbell Ring can run off its existing power supply for a continuous charge (see step 6).

NOTE: Ring is not compatible with most intercom systems.

If you DON'T have an existing doorbell Ring can run off its built in battery and last 6-12 months between charges.

If you receive frequent motion events, you may need to charge your Ring more frequently.

**Getting Ready for Setup** Step 1


Say "Hello" to the back of your Ring

Setup Button – You'll be instructed to push the orange **setup button** during the in-app setup (see step 3).

While in setup mode, the light on the front of your Ring Doorbell will spin.

Charging Port – Plug the orange cable into the charging port to charge your Ring Doorbell.

Setup Button Charging Port



Download the Ring app



The Ring app will walk you through the entire installation process, but if you prefer to reference a hard copy, use this manual.

Visit: ring.com/app



## Visit the online setup guide for extra help

We also have an online guide with videos and tutorials to help you set up and use your Ring Video Doorbell.

Visit: ring.com/setup

# Step 2

Perform the in-app setup

The Ring app will walk you through this process.

Download the Ring app by visiting ring.com/app



Tap the plus sign in the Ring app to set up a new device, and select Video **Doorbell** when prompted.

Perform in-app setup near your router. **You'll need your** network name and Wi-Fi password.

# Step 3

Push the front button to test video

While **inside near your router**, push the button on the front of your doorbell to see live video in the Ring app. Then, perform this same test while outside.



If video quality is not as good outdoors as it was indoors, you may need to move your router closer to your door or invest in a Wi-Fi extender.

Learn more at: ring.com/extender

## Step 4

Remove your existing doorbell (optional)

> If you're replacing a wired doorbell, first turn off the power at the breaker. Then, remove your doorbell from the wall, and disconnect the wires.



If your existing doorbell has a diode, you'll need to use the diode included with your Ring Doorbell for installation.



# Step 5

Install the mounting bracket

Take everything that came in the box (along with a power drill if you're installing on **stucco**, **brick** or concrete), to the spot where you're installing your Ring Doorbell.




Snap the provided level onto the mounting bracket, and align the bracket accordingly.

Then, remove the orange tape, and use the mounting bracket as a template to mark four corner holes for your screws.

(continued)

Installing the mounting bracket

On **stucco**, **brick** or **concrete**, install the anchors using the provided drill bit and a power drill before installing the mounting bracket.



On **wood** or **siding**, you can skip this part and screw the bracket directly onto your wall.

If you have one, it may help to use a smaller drill bit to drill

pilot holes first.

(continued)

Drive the screws into the anchors

flush with the mounting

bracket and the bracket

If the wall isn't flat.

make sure you don't

screw the bracket in so

tightly that it bends.

is flat against the wall.

or directly into the wall until they're

Use the star-shaped end of your Ring screwdriver to tighten the **security** screws on the bottom of your Ring Doorbell.

Secure your Ring Doorbell

The front light on your Ring Doorbell uses a number of patterns to

communicate messages.

Here are some common ones:

Ring Light Patterns

Solid

Turning alerts on or off:

alerts for Rings or Motions on or off in the Ring app

**Answering Your Door** 

When someone is at your door, you

can perform the following actions:

Disable/enable your

Mute/unmute your speaker

microphone

Zoom in/out

Need Help?

For additional help, visit: ring.com/help

For immediate assistance, we're available 7 days a week at: help@ring.com

US 1 800 656 1918

UK 01727 263045

AU 1 300 205 983

NZ +64 9 887 9871

Mexico (D.F) 52 55 8526 5445

For a list of all our customer support

that to which the receiver is connected. Worldwide +1 310 929 7085

Consult the dealer or an experienced radio/TV technician for

Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.ring.com/DoC.pdf. Protect the device from direct sunlight. Install the device at dry

device must be charged only within a building in a dry state.

This device complies with Part 15 of the FCC Rules. Operation

is subject to the following two conditions: (1) this device may

For best results, use type Li-Ion batteries. Install only new

batteries in the correct polarity, as indicated in the battery

compartment, may shorten the life of the batteries or cause

batteries to leak. Do not mix old and new batteries. Do not

per state and local guidelines.

the following measures: Reorient or relocate the receiving antenna.

user's authority to operate the equipment.

mix Alkaline. Standard (Carbon-Zinc) or Rechargeable (Nickel

Warning: Changes or modifications to this unit not expressly

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of

protection against harmful interference in a residential

the FCC Rules. These limits are designed to provide reasonable

frequency energy and, if not installed and used in accordance

with the instructions, may cause harmful interference to radio However, there is no guarantee that interference will not occur

in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from

encouraged to try to correct the interference by one or more of

installation. This equipment generates, uses and can radiate radio

Cadmium) or (Nickel Metal Hydride) batteries. Do not dispose of batteries in fire. Batteries should be recycled or disposed of as

approved by the party responsible for compliance could void the

not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

locations and protect it against rain and humidity. The device may not get contact to salt water or other conductive liquids. The



NG. ALWAYS HOME, and CHIME are trademarks Bot Home Automation, Inc.



Step 6

Connect the wires coming out of your wall to the screws on the bracket. Note that it doesn't matter which wire connects to which screw.



The wiring must be connected to a transformer with a voltage of 8VAC - 24VAC and an internal

doorbell or resistor. DC transformers and (therefore) most intercoms are not supported. How and when to

If your doorbell is digital (i.e. plays a melody), attach the included diode to the two screws on your bracket.

If it's mechanical (i.e. goes "dingdong"), DO NOT use the diode.



If you have a digital doorbell, connecting the diode the wrong way won't do any harm. If your doorbell


Learn more at ring.com/diode

doesn't ring, just reverse the diode.

# Step 7

Attach Ring Doorbell to the bracket

Doorbell with the slots on the bracket. Push firmly towards the wall and then down until you feel a click.



# Then, restore power at the breaker.

Step 8

Pushed Ring Speaker

Charge Percentage

In Setup Mode

Flashing

You can toggle

RING ALERTS

MOTION ALERTS

numbers, visit: ring.com/callus Access the Ring Plus menu



Connect the wires (optional)

